

## ASSEMBLING INSTRUCTION

## LEGEND

### WINDSHIELD

### KN1300-25

[WWW.BARRACUDAMOTO.COM](http://WWW.BARRACUDAMOTO.COM)

- |  |  |  |
|--|--|--|
| 1. ALLEN SCREW M5X30<br>VITE A BRUGOLA M5X30<br>TORNILLO ALLEN M5X30<br>INBUSSCHRAUBE M5X30<br>VIS ALLEN M5X30 | 3. SPACER TUBE H.10<br>DISTANZIALE H.10<br>DISTANCIADOR H.10<br>Distanzrohr H.10<br>ESPACEUR H.10              | 5. TEFLON WASHERS Ø5<br>RONDELLA TEFLON Ø5<br>ARANDELAS DE TEFLON Ø5<br>TEFLONSCHIBE Ø5<br>RONDELLE EN TEFLON Ø5 |
| 2. MOTORCYCLE BRACKET<br>STAFFA MOTOCICLETTA<br>SOPORTE DE MOTOCICLETA<br>MOTORRADHALTERUNG<br>SUPPORT DE MOTO | 4. ALLEN SCREW M5X16<br>VITE A BRUGOLA M5X16<br>TORNILLO ALLEN M5X16<br>INBUSSCHRAUBE M5X16<br>VIS ALLEN M5X16 | 6. RUBBER WASHERS<br>RONDELLA GOMMA<br>ARANDELAS DE CAUCHO<br>GUMMISCHIBE<br>RONDELLE EN CAOUTCHOUC              |
|  |  | 7. THREADED THICKNESSES<br>SPESSORE FILETTATO<br>ESPACIADOR ROSCADO<br>GEWINDE ABSTAND<br>ESPACEUR FILETÉ        |

